

> CYFORM[®] 22 EPOXY TOOLING PREPREG

TECHNICAL DATA SHEET



DESCRIPTION

CYFORM 22 is a proven, high-performance and cost-effective, low-temperature-curing epoxy tooling system available with either carbon or glass reinforcement.

CYFORM 22 allows high-quality tooling laminates to be produced directly from a low-temperature master model. After vacuum bag/oven or autoclave processing for the initial cure, the tool laminate can be de-molded and post-cured "free-standing".

CYFORM 22 is supplied in roll form with a standard roll length of 25 yards (25 meters). Standard material width is 50 inches (1000 – 1270mm). Materials are shipped frozen and in insulated boxes.

FEATURES & BENEFITS

- Provides versatile low temperature curing options from 7 days at 68°F (20°C) to 5 hours at 130°F (55°C)
- Manufactured to ensure uniform resin distribution in fabrics with <1% volatile content
- Formulated for long-term thermal oxidative stability during normal 350°F (177°C) service
- Exhibits low and predictable shrinkage with both carbon and glass fiber reinforcement
- Closely matches the thermal expansion coefficient of composite parts reducing dimensional inaccuracies and residual stress levels
- When used with a surface gel coat, produces tools of extremely low void content via vacuum-bag-only processing if autoclave facilities are not available
- Determined safe to use via extensive toxicological screening (contains no MDA or VCHDs)

SUGGESTED APPLICATIONS

- Tools used for manufacture of composite components where the master model is made of high-CTE material
- Ideally suited for the rapid manufacture of complex mold tooling; e.g., Formula 1 race cars

CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

CHARACTERISTICS & PROPERTIES

Table 1 | Carbon Prepreg Characteristics

Property	CP 200 ¹	CP220 ²	CP 650
Weave Style	2x2 Twill	2x2 Twill	2x2 Twill
Fabric Weight, gsm	200	220	650
Warp, ends/in (ends/cm)	12.5 (4.92)	14.0 (5.5)	10.0 (3.94)
Fill, ends/in (ends/cm)	12.5 (4.92)	14.0 (5.5)	10.0 (3.94)
Prepreg Weight, gsm	364	366	1048
Resin Weight, %	45	40	38
Volatile Content, %	<1	<1	<1
Shelf Life at 0°F (-18°C), months	>6	>6	>6
Tack Life at 68°F (20°C), days	2 – 3	2 – 3	2 – 3
Work Life at 68°F (20°C), days	3 – 4	3 – 4	3 – 4
Gel Time at 68°F (20°C), hours	108	108	108
Gel Time at 105°F (40°C), hours	8	8	8
Cured Ply Thickness, autoclave, in (mm)	0.009 (0.23)	0.0095 (0.24)	0.026 (0.66)

¹ Primarily supplied by Cytec Engineered Materials US facilities

² Primarily supplied by Cytec Engineered Materials European facilities

Table 2 | Carbon Tooling Laminate Properties

Property	Value		
Tg, °F (°C) *	400 (204)		
Shrinkage, %	0.031		
CTE, °F ⁻¹ (°C ⁻¹)	1.4x10 ⁻⁶ (2.5x 10 ⁻⁶)		
Void Content: Autoclave, %	< 0.5		
Void Content: Vacuum Bag, %	< 2.0		
CP200 Quasi-isotropic Lay-up			
Flexural Modulus, Msi (GPa)	After post-cure	at 68°F (20°C)	6.7 (46)
		at 195°F (90°C)	6.5 (45)
		at 350°F (177°C)	5.5 (38)
		After thermal cycling ³	at 68°F (20°C)
		at 350°F (177°C)	5.0 (35)

³ Testing performed after 1500 thermal cycles as below

i) Heat to 350°F (177°C) at 3.6°F/minute (2.0°C/minute). ii) Dwell at 350°F (177°C) for 1 hour. iii) Cool to 68°F (20°C) at 5.4°F/minute (3.0°C/minute).

* **NOTE:** Tg data is not applicable for U.S. export control classification or licensing. For export-related information please contact us.

> CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

Table 3 | Glass Prepreg Characteristics

Property	GPT 160	GPT 400	GPT 870
Weave Style	2x2 Twill	2x2 Twill	2x2 Twill
Fabric Weight, gsm	160	400	870
Warp, ends/in (ends/cm)	12.0 (4.72)	6.0 (2.36)	10.0 (3.94)
Fill, ends/in (ends/cm)	11.5 (4.53)	6.7 (2.64)	9.5 (3.74)
Prepreg Weight, gsm	281	635	1243
Resin Weight, %	43	37	30
Volatile Content, %	<1	<1	<1
Shelf Life at 0°F (-18°C), months	>6	>6	>6
Tack Life at 68°F (20°C), days	2-3	2-3	2-3
Work Life at 68°F (20°C), days	3-4	3-4	3-4
Gel Time at 68°F (20°C), hours	108	108	108
Gel Time at 105°F (40°C), hours	8	8	8
Cured Ply Thickness, autoclave, in (mm)	0.006 (0.16)	0.013 (0.33)	0.025 (0.64)

Table 4 | Glass Tooling Laminate Properties

Property	Value		
Tg, °F (°C) *	400 (204)		
Shrinkage, %	0.15		
CTE, °F ⁻¹ (°C ⁻¹)	8.1 x 10 ⁻⁶ (14.6 x 10 ⁻⁶)		
Void Content: Autoclave, %	< 0.5		
Void Content: Vacuum Bag, %	< 2.0		
GPT Quasi-isotropic Lay-up			
Flexural Modulus, Msi (GPa)	After post-cure	at 68°F (20°C)	3.7 (26)
		at 195°F (90°C)	3.4 (23)
		at 350°F (177°C)	2.4 (16)
		After thermal cycling ¹	at 68°F (20°C)
		at 350°F (177°C)	2.5 (17)

1 Testing performed after 1500 thermal cycles as below
 i) Heat to 350°F (177°C) at 3.6°F/minute (2.0°C/minute). ii) Dwell at 350°F (177°C) for 1 hour. iii) Cool to 68°F (20°C) at 5.4°F/minute (3.0°C/minute).

* **NOTE:** Tg data is not applicable for U.S. export control classification or licensing. For export-related information please contact us.

MANUFACTURING PROCEDURES FOR AUTOCLAVE CURED LAMINATES

These procedures are designed to produce consistent, high-quality tooling laminates. Minor deviations can have unexpected and undesirable effects on the final product. Please consult Cytec Engineered Materials before deviating from these procedures.

Master Model Construction

- A master model constructed of epoxy modelling boards or epoxy composite is recommended
- If master models constructed from urethane or phenolic modelling boards must be used, a surface gel coat should be used as a suitable barrier material
- The master model should be soundly constructed to withstand the autoclave cycle. Solid models are preferred, but hollow models may be used if they are suitably sealed. Hollow models should never be enveloped bagged
- The master model should be cycled at temperature and pressure above that of the desired cure cycle before beginning lay-up of the tool. Any leaking, softening or out gassing of the master model during tool cure can degrade the performance of the finished product

Master Model Preparation Procedure

The following steps should be completed to prepare the surface of the master model for tool lay-up:

1. Seal the surface of master model with an epoxy surfacing resin such as CYFORM[®] CHP102
NOTE: Polyester and other acid-catalyzed surface coatings are not recommended for use with CYFORM tooling prepregs. Some types of polyurethane sealers can cause an adverse reaction with the resin system, producing an unacceptable finish.
2. Thoroughly degrease the master model surface ensuring all solvent is removed
Thorough degreasing may require use of elevated temperature.
3. Apply a semi-permanent, solvent-based release sealer such as Frekote[®] B-15 or Frekote[®] 700 NC to the master model surface following the manufacturer's instructions
4. Apply multiple coats of a suitable carnauba paste wax to the master model surface following the manufacturer's instructions
5. Apply 1/4 inch (6.0mm) perimeter dam of bag sealant tape to the master model surface to define the edge of the tool

Prepreg Thawing Procedure

- Allow the prepreg rolls to warm to room temperature before opening the protective bag
Prepreg rolls are considered sufficiently warm when condensation is no longer visible on the outside of the bag.
- Do not remove the prepreg rolls from the freezer and leave them out overnight
- Ensure sufficient material is available to complete the job allowing for 10 – 15% scrap

CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

General Lay-up Instructions

- Materials should be laid up in accordance with the laminate schedules in Figure 1 and Figure 2
- Cleanliness is very important during the lay-up procedure. Avoid introducing any contaminants into the lay-up, i.e. paper, polythene or release film, as these will adversely affect the tool laminate and may lead to premature tool failure
- To avoid bridging, no single piece of prepreg should ever be laid up around more than one corner
- To avoid wrinkling, ensure that prepreg is spliced in corners and any female tight radii
- Overlap joints of 1/8 inch to 1/4 inch wide (3.0mm to 6.0mm) are recommended on the first ply only. Butt jointing is preferable on subsequent plies but care must be taken so that the joints on each ply are staggered (do not occur above one another). If overlapping is unavoidable on subsequent plies ensure the overlap is a maximum of 1/8 inch (3.0mm) wide and that overlaps are staggered

NOTE: The tool must be laid up and cured within the work life of the first ply of prepreg.




Figure 1 | Suggested Carbon Laminate Schedules

CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

CYFORM 22: 0.24 (6mm) inch Laminate Schedule

Ply No.	Dir. (°)		Material Type
13	0	██████████	GPT160/22
DEBULK (OPTIONAL)			
12	0	██████████	GPT400/22
11	45	██████████	GPT400/22
10	0	██████████	GPT870/22
9	45	██████████	GPT870/22
DEBULK			
8	0	██████████	GPT870/22
7	0	██████████	GPT870/22
6	0	██████████	GPT870/22
5	45	██████████	GPT870/22
DEBULK			
4	0	██████████	GPT870/22
3	45	██████████	GPT400/22
2	0	██████████	GPT400/22
DEBULK			
1	0	██████████	GPT160/22
MODEL			

———— Axis of Symmetry ————

Figure 2 | Suggested Glass Laminate Schedule

Tool Lay-up Procedure

1. Lay the first ply of prepreg on the master model surface oriented at 0°
The initial choice of which direction will be 0° is arbitrary, but, once chosen, subsequent angles must be measured relative to this direction.
2. Debulk the lay-up per the following steps:
 - a. Cover the lay-up with a suitable (P3) pin pricked release film (e.g. FEP) ensuring no bridging
 - b. Lay 7781, 7500 or equivalent glass fabric over the release film to act as a breather
Ensure no bridging of the glass fabric by cutting the fabric to fit complex areas.
Do not use a non-woven polyester breather unless a peel ply is first applied over the release film. Filaments from the polyester breather left in the laminate may cause premature tool failure.
 - c. Apply a vacuum bag, pull a minimum of 25 inches Hg vacuum and hold as indicated in Table 5

Table 5 | Debulk Cycle Hold Times

Ply	Debulk Hold Time
First	60 minutes
Second through final	30 minutes

- d. Remove vacuum bag and breather materials and set to one side for future use

> CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

3. Lay the second and third plies of prepreg oriented at 0° and ±45°, respectively
4. Continue lay-up of plies per the appropriate schedule, debulking when called for as described in Step 2

Final Bagging Procedure

Bag the completed tooling laminate according to the following steps. Refer to Figure 3 for details.

1. Place two or more thermocouples into the prepreg between ply 1 and ply 2, ideally situated near the thickest part of the master model and in a trim area
2. If secondary bonding to the tool laminate is required, apply 1 ply of nylon peel ply to the lay-up, ensuring no bridging
3. Cover the lay-up with a solid release film and seal the film perimeter to the master model with sealant tape
4. Pin prick the solid release film every 4 to 6 inches (75 to 100mm) across the surface of the tool. The pin pricks allow vacuum connection between the laminate and breather pack.
5. Apply the breather pack according to the following steps:
 - a. Cover the lay-up with a 10 ounce (280gsm) non-woven polyester fabric ensuring no bridging
 - b. Lay 2 – 3 inch (50 – 75mm) wide glass fabric tape in a 2 ft x 2 ft (500mm x 500mm) grid over the polyester fabric to provide a good air path over the entire tool
6. Locate a minimum of two vacuum ports, on breather pads, for a laminate up to 20 square feet (2 square meters) and another port for each additional 10 square feet (1 square meter)

Always use an even number of vacuum ports.

Do not locate vacuum ports directly on top of the laminate. Position them against the master model or in tucks in the vacuum bag ensuring they are connected to the breather pack.

7. Cover the lay-up with a good-quality nylon bagging film, ensuring no bridging in the bag
8. Check the vacuum integrity by pulling a full vacuum (28" Hg) then disconnecting the vacuum source. If the bag loses more than 2 inches of Hg in 15 minutes check and seal leaks.




Figure 3 | CYFORM 22 Bagging Scheme

> CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

Recommended Cure Procedure

1. Apply a minimum of 26 inches of Hg vacuum
2. Apply 60 – 120 psi (4 – 7 bar) autoclave pressure [90+ psi (6+ bar) preferred]
Vacuum may be vented at 25 psi (1 bar) if desired.
3. Heat the laminate at a rate of 1 – 3°F/minute (0.5 – 1.0°C/minute) until the lagging thermocouple reaches a cure temperature of 115 ± 2 °F (45 +3/-0°C)
To promote even heat up do not allow autoclave temperature to exceed 10°F (5°C) above the cure temperature.
4. Hold the laminate at 115 ± 2 °F (45 +3/-0°C) for a dwell time of 10 hours minimum
5. Cool the laminate under pressure to 85°F (30°C) at 5°F/minute (3.0°C/minute) maximum rate

Alternative Cure Schedule

Alternatively, the laminate can be cured by following Steps 1 – 5 but using the cure temperatures and dwell times indicated in Table 6. Autoclave curing below 104°F (40°C) is not recommended. If it is necessary to cure at 104°F (40°C) or below a surface gel coat may be required. Please consult Cytec Engineered Materials for details.

Table 6 | Alternative Cure Schedules

Cure Temperature	Dwell Time
86°F (30°C)	48 hours
95°F (35°C)	25 hours
105°F (40°C) ²	14 hours
115°F (45°C) ¹	10 hours
122°F (50°C) ¹	6 hours
131°F (55°C)	5 hours

¹ Preferred cure cycle

² Minimum autoclave cure temperature without gel coat

Release Procedure

1. Remove the bagging materials from the laminate
Remove peel ply at this time only as necessary to allow backing structure attachment.
2. Attach support structure if desired
All composite tools require some kind of support structure. This may take the form of an extended flange or a complex structure designed to prevent deflection under normal service conditions. These usually fall into one of three categories.
 - **Egg crate structures:** This kind of structure is prefabricated from either solid or honeycomb cored composite panels and can be applied before demolding or after post-cure. Attachment is by wet lay-up “cleats”, silicone RTV adhesive or mechanical fasteners. The structure should be spaced 1/8 inch (3mm) away from the back face of the tool laminate.

> CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

- **Tubular structures:** This kind of structure is also prefabricated using composite tube sections and can be applied before de-molding or after post-cure. Attachment is by wet lay-up “cleats” or mechanical fasteners. Additional pads are usually added to the back of the tool laminate to spread loads at the local attachment points.
 - **Integral stiffeners:** This method can provide a very quick and cost effective support structure when used in conjunction with an inexpensive metal support trolley. In addition, accuracy benefits can be obtained by effectively “locking” the tool into shape on the model thereby reducing spring in/out during post-cure.
3. Carefully release the laminate around its entire periphery and ease it off the master model
Always use “soft” plastic wedges; never use metal chisels or scrapers.

NOTE: In its partially cured state the tool laminate will be brittle. Do not attempt any trimming or finishing operations or use any solvents on the laminate until after post-cure.

Post-cure Procedure

Post-cure the laminate following the steps for either Post-cure A (preferred) or Post-cure B listed below. Refer to Figure 4 for details.

Post-cure A

1. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 140°F (60°C)
2. Heat tool at 20°F/hour (10°C/hour) to 390°F (200°C) and hold for 5 hours
3. Cool tool to room temperature at 5°F/minute (3°C/minute)

Post-cure B

1. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 140°F (60°C) and hold for 2 hours
2. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 210°F (100°C) and hold for 2 hours
3. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 285°F (140°C) and hold for 2 hours
4. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 360°F (180°C) and hold for 2 hours
5. Heat tool at 2 – 4°F/minute (1 – 2°C/minute) to 390°F (200°C) and hold for 5 hours
6. Cool tool to room temperature at 5°F/minute (3°C/minute)

For information regarding post-cures suitable for lower temperature service please contact Cytec Engineered Materials.

CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET




Figure 4 | CYFORM 22 Post-cure Profiles

Putting the Tool into Service

1. Clean the tool surface to remove all traces of the release used during manufacturing
A cleaner such as a mild cutting/polishing compound is recommended (e.g., Frekote[®] PMC). Wiping with solvent will not remove wax.
2. For new tools and after refurbishment of older tools, apply 2 or 3 coats of a tool surface sealer such as Frekote[®] B-15 per manufacturer's instructions
For best results cure the final coat of tool surface sealer at the end use temperature of the tool.
3. Apply a production release agent per manufacturer's instructions

The tool is now ready for 350°F (177°C) service.

PRODUCT HANDLING AND SAFETY

Cytec Engineered Materials recommends wearing clean, impervious gloves when working with prepreg materials to reduce skin contact and to avoid contamination of the product.

Materials Safety Data Sheets (MSDS) and product labels are available upon request and can be obtained from any Cytec Engineered Materials Office.

DISPOSAL OF SCRAP MATERIAL

Disposal of scrap material should be in accordance with local, state, and federal regulations.

> CYFORM[®] 22 TOOLING PREPREG

TECHNICAL DATA SHEET

CONTACT INFORMATION

GLOBAL HEADQUARTERS

Tempe, Arizona
tel 480.730.2000
fax 480.730.2088

NORTH AMERICA

Olean, New York
tel 716.372.9650
fax 716.372.1594

Winona, Minnesota
tel 507.454.3611
fax 507.452.8195

Greenville, Texas
tel 903.457.8500
fax 903.457.8598

Springfield, Massachusetts
tel 1.800.652.6013 (USA)
tel 1.973.357.3193 (Outside the USA)

Anaheim, California
tel 714.630.9400
fax 714.666.4345

Cytec Carbon Fibers LLC
Piedmont, South Carolina
tel 864.277.5720
fax 864.299.9373

Havre de Grace, Maryland
tel 410.939.1910
fax 410.939.8100

Orange, California
tel 714.639.2050
fax 714.532.4096

D Aircraft Products, Inc.
Anaheim, California
tel 714.632.8444
fax 714.632.7164

EUROPE AND ASIA

Wrexham, United Kingdom
tel +44.1978.665200
fax +44.1978.665222

Östringen, Germany
tel +49.7253.934111
fax +49.7253.934102

Shanghai, China
tel +86.21.5746.8018
fax +86.21.5746.8038

DISCLAIMER: The data and information provided in this document have been obtained from carefully controlled samples and are considered to be representative of the product described. Because the properties of this product can be significantly affected by the fabrication and testing techniques employed and since Cytec Engineered Materials (CEM) does not control the conditions under which its products are tested and used, CEM cannot guarantee that the properties provided will be obtained with other processes and equipment. CEM has the right to change any data or information when deemed appropriate.

All trademarks are the property of their respective owners.